

Safety Information

Before using the device, read these precautions carefully. Follow these precautions and instructions to ensure optimal product performance and to avoid danger and legal or regulatory violations.

Fire-proof Precautions

- Keep the device away from fire or heat sources, including electric heaters, ovens, stoves, and candles; otherwise, the shell of the device may become hot or melt, causing fire in extreme cases.
- Replace deteriorated cables or power socket components on the power supply line or near the device in a timely manner to eliminate safety risks.



31500BQV_03

Potentially Explosive Area

- Do not place or operate the device in an environment that contains flammable or explosive gas or smoke.
- Do not place flammable or explosive materials near the device.

General Safety Precautions

- Do not lead the strength member of the optical fiber or other metal parts indoors. Do not install telephone lines, network cables, power adapters, or power adapter cables outdoors. These measures will help to prevent damage to the device and injury to people, which are especially possible during thunderstorms.
- If the power adapter is damaged due to human factors, and the inside circuit is exposed, do not touch the exposed parts. Otherwise, security risks are present.
- Keep the device out of the reach of children. Components and accessories are small and could pose a choking risk.
- Looking directly at an optical port may injure your eyes.

- Do not use any power adapters that are not in the standard configuration; otherwise, the device may be abnormal or unsafe.
- If a backup power unit (BBU) is available in the packing box, do not disassemble it, refit it, or put it in a fire; otherwise, it may create a safety risk.

Instructions for Use

- Use the device in a clean and well-ventilated indoor environment, out of direct sunlight.
- Store devices and accessories in temperature -10°C to $+35^{\circ}\text{C}$ and relative humidity 30%–85% RH for at most 9 months. If the ambient temperature or relative humidity is too high or too low, the device may be faulty.
- Install the device in strict compliance with the requirements of the supplier. Ensure there is at least 10 cm space surrounding the device for heat dissipation. During installation, keep the device away from flammable objects and electric appliances that generate strong magnetic or electric fields, including microwave ovens,

refrigerators, and mobile phones.

- The input voltage range should comply with the local power grid.
- The power supply voltage of the device must meet the requirements on the input voltage of the device.
- Before using the power adapter, check that the adapter is intact.
- Before connecting or disconnecting cables, stop using the device, switch off the power, and verify that your hands are dry.
- When there is lightning, switch off the power and disconnect all cables, including the power cable, optical cable, and network cable.
- Prevent objects from entering the device through the heat dissipation hole. Prevent water or other liquids from entering the device.
- Do not cover the device with any objects which may block heat dissipation; otherwise, the device may overheat and become faulty.
- If an abnormality occurs, for example, liquid enters the device, or the device generates

smoke, unusual sounds, or odors, stop using the device immediately. Switch off its power, and disconnect all cables to the device, including the power cable, optical cable, and network cable.

- Before cleaning or maintaining the device, stop using it, close all apps, and disconnect all cables.
- Do not use any strong chemicals, detergents, or other chemical agents. Instead, use a clean, dry, soft cloth to clean the shell and accessories of the device.
- Keep the device dry when it is stored, transported, or used. Prevent the device from colliding with other objects; otherwise, the device and its accessories may be damaged and become faulty.
- No unauthorized unit or individual may disassemble or modify the device or accessories.
- Dispose of the packing materials, exhausted batteries, and old or abandoned devices in accordance with local laws and regulations. Recycling them is strongly recommended.

Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, user manual, or package reminds you that all electronic products must be taken to separate waste collection

points at the end of their lifecycles. They must not be disposed of as household garbage. It is the responsibility of users to dispose of the device at proper collection points for recycling of waste electrical and electronic equipment (WEEE) according to local laws.

Proper collection and recycling of your device helps ensure that electrical and electronic equipment (EEE) waste is recycled in a manner that conserves valuable materials and protects human health and the environment. Improper handling, accidental breakage, damage, and/or improper recycling at the end of the product lifecycle may be harmful to human health and the environment. For more information about where and how to drop off your EEE waste, contact your local authorities, retailer, or household waste disposal service.

Disposal of the device is subject to WEEE Directive Recast (Directive 2012/19/EU). The purpose of separating WEEE from other waste is to minimize the potential environmental impacts and human health risks caused by any hazardous substances.

Reduction of hazardous substances

This device is compliant with the REACH Regulation [Regulation (EC) No 1907/2006] and RoHS Directive Recast (Directive 2011/65/EU).

**Copyright © Huawei Technologies
Co., Ltd. 2024. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.